

Wet Application

SURFACE PREPARATION

- Clean the surface that the cling vinyl is being applied to with Windex or Isopropyl Alcohol so that it is free of all grease and dirt.

INSTALL

- For best results you should install this vinyl like you would any other decal.
- Spray back of vinyl and window surface with a mixture of ½ tsp. (approx.) dish soap in 1 litre of water. This provides a slippery surface so you are able to position decal in area as required.
- Using squeegee supplied, wrap a paper towel around squeegee edge so as not to scratch surface of vinyl. Starting at middle of decal, gently but firmly push to remove water from centre to outer edge of decal in smooth even strokes until you have smoothed decal to surface. **If decal is applied dry there is a greater chance of air pockets therefore vinyl will not adhere properly and will not be visually pleasing.**

STORAGE

- When decal is not in use, store flat on original liner paper in clean area.

